



ELEVATION

NOTES

1. VALVE STEM AND VALVE SHALL BE PLACED PLUMB.
2. ON EXISTING CHAMBERS FASTEN BRACKET TO WALL USING 15 mm X 75 mm LONG LAG SCREWS WITH 75 mm LONG EXPANSION SHIELDS.
3. ON PROPOSED CHAMBERS, BRACKET SHALL BE FASTENED TO THE WALL USING 15 mm X 200 mm LONG BOLTS WITH WASHERS AND NUTS.

ALL DIMENSIONS IN MILLIMETRES EXCEPT WHERE NOTED.



**VALVE STEM EXTENSION
AND BRACKET**

DWG. DATE: 1991 11
REVISION NO.: 3
REV. DATE: 2014 04
SCALE: N.T.S.

S-220.040